

Before You Start



Confirm the flow switch assembly is complete. It should include a threaded retaining nut and a protective plug on the electrical connections.



Isolate power and switch off the water pump before beginning installation.

Installation Steps



1. Trim the paddle to the **first line from the bottom** of the paddle.
2. Remove the existing flow switch and install the new flow switch into the threaded fitting.
3. Ensure the **arrow on the flow switch points in the direction of water flow**.



4. Disconnect the old flow switch connector and connect the new flow switch connector.
5. Secure the quick connector wiring firmly into the controller, then restore water flow to the pipe.
6. With the water flowing, check for vibration by gently holding the top of the flow switch. If vibration is present, rotate the flow switch so the paddle is angled **up to 45° from perpendicular** to the direction of flow.