





Piping Diagram for Connection to Econergy® Heat Pump Ready Hot Water Cylinder — FOR PLUMBER



Please ensure inlet (A) is plumbed to the bottom of the cylinder (A) and outlet (B) is plumbed to the top of the cylinder (B).

*For standard HWC please contact Hot Water Heat Pumps Ltd for further information

Wiring Diagram – FOR ELECTRICIAN



A pre-made CAT-5/6 cable is required for installation of Econergy heat pumps.



WARNING: Incorrect connection of CAT cable WILL cause fault or board failure.

Warranty Registration and Installation Declaration Form

Please ensure the commissioning installer(s) completes this warranty registration and installation declaration form. Send to Hot Water Heat Pumps via post or email using the address below.

Owners Name

Product Serial Number

Installation Date

Installation address

Declaration: I have installed and commissioned this Econergy water heater at the address below in compliance with the manufacturer's instruction manual.

COC No: _____

Installer Name

Installer Company Name/ Trading Name

Signed

Date

Installer email address

Secondary installer (electrician or plumber)

Secondary Installer Company Name/ Trading Name

Signed

Date

Installer email address



info@waterheating.co.nz
PO Box 21586, Henderson, Auckland 0650

0800 33 66 33

Econergy[®]
The smarter way to heat water™

www.econergy.co.nz